



Sierra Wireless U302, U305,
U308, 309, AC500, AC504,
USB301, USB307, USB309;
Novatel C777, PC770,
USB1000; ZTE MF633BP+,
MF668+, MF633+ Adapter.

399936

219936



Adapter, 6 inch RG-174 cable with
reverse TNC-FME Male Connectors

359937

219937



Mini USB to
Micro USB
Charging Adapter

859967



Mini USB Charging
Adapter for use
with *iPhone®
*iPhone is a
registered trademark
for Apple Computer

859979

2D9979



SMA Female to SMA Male
(6' RG174 coax cable)

951130

291130



SMA Male to SMA Female
(10' RG58 low loss foam coax cable)

951147

291147

Cellular Phone Adapter Guide



3301 East Deseret Drive, St. George, UT 84790

For additional Technical Support visit www.WilsonElectronics.com

or email at: tech@wilsonelectronics.com

Phone: 866-294-1660 Local: 435-673-5021 Fax: 435-656-2432

www.twitter.com/WilsonCellular www.facebook.com/WilsonCellular

CellularPhone_AdapterGuide_Rev5_01.10.12



\\nas\Production_Dept\Quality Control Procedures (UN: production PW: production)

DISCONTINUED



Universal Velcro Instruction Paper
Motorola V60 series adapter
(except V60p, V60x, V66)

352007

212007



Sierra Wireless "Compass" 597, 597U,
Mercury 885; Novatel U727, USB727;
Pantech UM175 adapter

359927

219927


DISCONTINUED



Universal Velcro Instruction Paper
Motorola V60p, V60s, V60SI,
V60x adapter

352014

212014



Adapter, 6" w/FME Male to
MCX Male connectors

359932


219932



Instruction Paper
Motorola V3 RAZR, V3c, V3i, V3r,
V3Maxx VE

352015

212015



Adapter, 20" RG174
Cable w/FME Male to
MCX connectors

359933

219933



Motorola L7 SLVR adapter

352017

212017



Adapter 6" RG174 Cable
w/ N Female to MCX Male
connectors

359934

219934



Pantech UMW190
Aircard Adapter

359935

219935



359919

219919

LG AX245, AX355, AX390, AX490, AX4270, AX4750, C1300, C1500, C2000, CE500, CG225, CU320, CU400, CU500, F7200, F9100, G4015, G4020, L1100, L1150, L1200, L1400, LX350, LX550, UX390, UX4750, VX3300, VX3400, VX4650, VX4700, VX5300, VX8500, VX9400, VX9900; Nokia 6215i, 6305i, 6315i; Pantech PG C-300, PN205, PN210, PX500; Samsung D807, P207, U420; UTStarcom G'zOne; LG VX-9100 "enV2"; LG VX-9700 "DARE"; adapter



352018

212018

Motorola W315 adapter



359921

219921

LG-VX8600, VX565 (Muziq) VL600; Pantech-UML290; Samsung A717, A727, A900, D807, i607 (Blackjack), R510 (Wafer), UTStarcom - UM150 (aircard) adapter



352019

212019

Motorola W755 adapter



359923

219923

Sierra Wireless 595 (except 595U); Franklin Wireless CDU-650 adapter



354008

214008

Universal Velcro Instruction Paper
Motorola i305, i315, i325, i355 adapter



359925

219925

HUAWEI EC360 adapter




DISCONTINUED



354009

214009


Instruction Paper
Motorola i205 adapter



DISCONTINUED

Sony, Ericsson, Edge PC card
GC82, GC83, GC85 adapter

355011 215011



Audiovox 2500 Series, CDM8200 Series
CDM8300 Series, CDM 8500; Mitsubishi
G75, G340, T200, T250; Samsung 850,
8500, A400, N200, N300, N330, N400,
T100; Uniden PCD2000A adapter


359915 219915



Sony Ericsson GC 89 adapter

355015 215015


DISCONTINUED



Merlin Wireless PC Card Adapter G100,
G2000 (T-Mobile & Voice Stream)

359916 219916

DISCONTINUED



Sony Ericsson W810

355016 215016



Audiovox 3220, 5220, 5220M; Sierra
Wireless Aircard 580, 3200, 3300, 5220,
5220M; Option GT-Max adapter


359917 219917

DISCONTINUED



Sony Ericsson W6001 adapter

355017 215017



Dell 5700, Merlin/Novatel EX720, S620,
S720, U630, U730, V620, V640, V740,
XU870 adapter

359918 219918



359909

219909

Universal Velcro Instruction Paper
Motorola C155, C290, E815/E816, MER-
LIN U720,V262,V265,V276,V323,V325,
V400,V710; Samsung A790,A795, i730,
MA700, N370; LG VX-9800; HTC Apache,
Dash/Excalibur/620, Hermes, Jasjam,
Mogul, PPC-6700, Tytn, XV6700, XV6800,
8525; Pantech-CDM180, PN-218, PN-300,
C3b; Novatel - Ovation U720 adapter

DISCONTINUED



356503

216503

Sanyo 5150, 7300 (RL7300)
adapter

DISCONTINUED



359910

219910

Universal Velcro Instruction Paper
Audiovox 100, 8150,T300; LG 4NEI,
VX2000,VX4400,VX4500; Mitsubishi, T300;
Motorola V200 series; Samsung A460,A600,
A610, N150, R225 adapter

DISCONTINUED



356505

216505

Sanyo 8100, 8200 adapter



359912

219912

Sierra Wireless Aircard 300, 350, 550, 555,
597e, 750, 775, 850, 860, PC3320;
Audiovox PC 3320 adapter



356808

216808

LG AX5000, CG300, PM-225,
UX5000,VX5200 Adapter



359914

219914

Small Universal Adapter

DISCONTINUED



357009

217009

Universal Velcro Instruction Paper
Kyocera 3225, K7, K9, KE413,
KE414, KE424, KE433, KX414,
KX424, KX433, KX434, KX440,
KX444, AKTIV series (K404,
K484, K480, K483, K494) adapter

DISCONTINUED



Kyocera KXI (SOHO) K4130
(SOHO) adapter

357012

217012

DISCONTINUED



Handspring/Palm One Treo 600
adapter

358501

218501

DISCONTINUED



Kyocera KX2, (Koi) adapter

357013

217013

DISCONTINUED



Palm One Treo 650, Treo 700W,
Treo 700WX adapter

358502

218502

DISCONTINUED



Instruction Paper

Kyocera KPC650 PC Card
adapter

357014

217014

DISCONTINUED



Palm Treo 750, 755p adapter

358505

218505

DISCONTINUED



Kyocera KX9c (Milan) KX16
(Candid) adapter

357015

217015



LG 110 Series, 510 Series, 520
Series, V111, VX1, VX10; Nokia
3285, 5100 series, 6100 series,
6300 series, 7100 series, (ex-
cept 5190, 6190, 7190 w/amps
Module); Sprint-Touchpoint 1100,
2200 adapter

359907

219907